### **Changes to the Datasheet Shape Files**

#### Background

There have been many requests to have attributes added to the Datasheet shape files and were adjusted to add new attributes, remove attributes, and to change attribute names to more meaningful names.

### Attributes Added

HT MOD – if it's a height mod station will be 'Y' CORS ID - it it's a CORS stations will have a CORS ID PACS SACS - if it's a 'PACS' or 'SACS' will be populated which one POS EPOCH – populated if exists VERT EPOCH – populated if exists (mainly just the Gulf) GEOID HT – populated if exists GEOID MOD – populated if exists (geoid model) N ACC HZ - populated if exists N ACC EH - populated if exists N ACC STD N - populated if exists N ACC STD E - populated if exists N ACC STD H - populated if exists N ACC CORR - populated if exists N ACC - populated if exists  $ECEF_X$  - populated if exists ECEF Y - populated if exists ECEF Z - populated if exists SPC ZONE - populated if exists. State Plane Coordinate Zone SPC NORTH - populated if exists (if SCALED POS SRCE no decimal places). SPC Northing SPC EAST - populated if exists (if SCALED POS SRCE no decimal places). SPC Easting SPC CONV - populated if exists. SPC Convergence Angle SPC CSF - populated if exists. SPC Combined Scale Factor UTM ZONE - populated if exists. Universal Transverse Mercator Zone UTM NORTH - populated if exists. UTM Northing UTM EAST - populated if exists. UTM Easting UTM CONV - populated if exists. UTM Convergence Angle UTM CSF - populated if exists. UTM Combined Scale Factor DYNAMIC HT - populated if exists MODEL GRAV - populated if exists MARKER - text and code SETTING - text and code STAMPING - text and code

## **Attributes Removed**

ELLIP\_SRCE – redundant, when populated it was same as POS\_SRCE POS\_CHECK – redundant, was a 'Y' if POS\_ORDER was in ['A','B','1','2','3'] VERT\_CHECK – redundant, was a 'Y' if VERT\_ORDER was in ['1','2','3'] ELLP\_ORDER – no longer getting added to database ELLP\_CLASS – no longer getting added to database SAT\_DATE – not useful DIST\_RATE – no longer used

# **Attributes Renamed**

Old Name	New Name
DEC_LONG	DEC_LON
ELEVATION	ORTHO_HT
ELEV DATUM	VERT DATUM
ELEV SRCE	VERT SRCE
ELEV ORDER	VERT ORDER
ELEV_CLASS	VERT_CLASS